

Drill 10mm hole in chassis rail in position shown. Weld bush supplied in hole as shown.



Use existing overflow pipe from swirl pot & push-fit onto bottom of expansion tank, shown here.

